IP Link Device Interface Communication Sheet

Revision: 3/24/2011

This document provides additional assistance with wiring your Extron IP Link enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific Extron IP Link enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Display Manufacturer: Sharp Firmware Version: 2.05

Model(s): LC-55LE620UT, LC-46LE620UT, LC-42LE620UT

Version History:

Driver Version	Date	IP Link Compiler	GC Version	Notes
2	3/23/2011	1.4.0	3.04	Extron Certified. Removed status due to commands not being documented by the manufacturer. Added Aspect Ratio. Added models LC-46LE620UT, and LC-42LE620UT.
1	1/27/2011	1.4.0	3.0.4	Initial version.

Driver Notes:

IP Link[®] Device Interface Communication Sheet

Revision: 3/24/2011

Control Commands & States:

Aspect Ratio*	Auto	Stretch	Si de Bar		
	Smart Stretch	Zoom	Dot by Dot		
	Toggle				
Audio Mute	On	Off	Toggle		
Channel TV (Step)	Up	Down			
Closed Caption	Toggle				
Input	TV	Input 1 Video	Input 2 Component		
	Input 3 Component	Input 4 RGB	Input 5 HDMI		
	Input 6 HDMI	Input 7 HDMI	Input 8 HDMI		
	Toggle				
Power Control	On	Off			
Volume (Discrete)	0 to 60 in steps of 1				

^{*}RGB input only supports Stretch and Dot by Dot Aspect Ratios.

MLC62 Supported Commands:

Audio Mute	On	Off	Toggle	
Channel TV (Step)	Up	Down		
Closed Caption	Toggle			
Input	TV	Input 1 Video	Input 2 Component	
	Input 3 Component	Input 4 RGB	Input 5 HDMI	
	Input 6 HDMI	Input 7 HDMI	Input 8 HDMI	
	Toggle			
Power Control	On	Off	RS232 Enable	
Volume (Discrete)	0 to 60 in steps of 1			

^{*}To keep RS232 port open during standby, the "RS232 Enable" needs to be configured on the "Power Off" button on MLC62.

IP Link Device Interface Communication Sheet

Revision: 3/24/2011

Cable and Adapter Requirements:


F/F RS-232 Null Modem Serial Cable

Notes for the Device:


Serial communication:

Port Type:RS-232Parity:NoneBaud Rate:9600Stop Bits:1Data Bits:8Flow Control:None

Pin Assignments Diagram:



Signal	Pin	Main Cable	Pin	Signal
RxD	2	\downarrow	2	RxD
TxD	3		3	TxD
GND	5		5	GND



Note: Captive screw connector may also be used as a serial connection.

General Notes: